

# A SHORT MATH PRIMER

## STRUCTURAL MECHANICS

---

### The ERAMCA Project

Environmental Risk Assessment and Mitigation on Cultural Heritage assets in Central Asia

V2022317

This work is licensed under a [Creative Commons “Attribution-ShareAlike 4.0 International”](https://creativecommons.org/licenses/by-sa/4.0/) license.



Co-funded by the  
Erasmus+ Programme  
of the European Union



Environmental Risk Assessment and Mitigation on Cultural  
Heritage Assets in Central Asia

# TABLE OF CONTENTS

Lecturer/students objectives

Introduction

Vectors

Differential equations



Co-funded by the  
Erasmus+ Programme  
of the European Union



Environmental Risk Assessment and Mitigation on Cultural  
Heritage Assets in Central Asia

# LECTURER/STUDENTS OBJECTIVES

---



Co-funded by the  
Erasmus+ Programme  
of the European Union



Environmental Risk Assessment and Mitigation on Cultural  
Heritage Assets in Central Asia

- 🎓 Present some mathematical tools used in the course.
- 👥 Convince the classroom to revise them as soon as possible!

# INTRODUCTION

---



Co-funded by the  
Erasmus+ Programme  
of the European Union



Environmental Risk Assessment and Mitigation on Cultural  
Heritage Assets in Central Asia

The objective of the lecture is to revise some topics useful for the course.

- Sum/difference  $\mathbf{C} = \mathbf{A} \pm \mathbf{B}$ .

Terms of  $\mathbf{C}$  are given by:

$$c_{ij} = a_{ij} \pm b_{ij}$$

The sizes of  $\mathbf{A}$  and  $\mathbf{B}$  must be identical.

- Product  $\mathbf{C} = \mathbf{AB}$ .

Terms of  $\mathbf{C}$  are given by:

$$c_{ij} = \sum_{k=1}^m a_{ik} b_{kj}$$

It has a meaning only if the number of columns in  $\mathbf{A}$  is equal to the number of rows in  $\mathbf{B}$  (i.e.,  $\mathbf{C} = \mathbf{A} \mathbf{B}$  ).  
 $(q \times p) \quad (q \times m)(m \times p)$

Multiplication of matrices is **not commutative** as in ordinary algebra (i.e.,  $\mathbf{AB} \neq \mathbf{BA}$ )!

- Transpose of  $\mathbf{A}$ .

The transpose  $\mathbf{A}^T$  is obtained by changing rows and columns of  $\mathbf{A}$ . If  $\mathbf{A} = \mathbf{A}^T$  square matrix  $\mathbf{A}$  is **symmetrical**. In case of a product, it is  $(\mathbf{AB})^T = \mathbf{B}^T \mathbf{A}^T$ .

- Determinant  $a = \det \mathbf{A}$  of  $\mathbf{A}$  (square matrix only):

$$a = \det \begin{bmatrix} a_{11} & a_{12} & \dots & a_{1n} \\ a_{21} & a_{22} & \dots & a_{2n} \\ \dots & \dots & \dots & \dots \\ a_{n1} & a_{n2} & \dots & a_{nn} \end{bmatrix} = \sum_{ijk} \epsilon_{ijk} a_{1i} a_{2j} a_{3k}$$

where:

$$\epsilon_{ijk} = \begin{cases} +1 & \text{if } ijk \text{ appears in the sequence } 12312 \\ -1 & \text{in the sequence } 32132 \\ 0 & \text{if in any other sequence} \end{cases}$$

If  $\det \mathbf{A} = 0$ , matrix  $\mathbf{A}$  is **singular**.



- Inverse  $\mathbf{A}^{-1}$  of  $\mathbf{A}$  (square matrix only).

Matrix  $\mathbf{A}^{-1}$  is such that:

$$\mathbf{A}\mathbf{A}^{-1} = \mathbf{I}$$

where  $\mathbf{I}$  is an **identity** matrix having zero on all off-diagonal positions and unity on each of the diagonal positions.

It is useful for the solutions of linear systems of equations  $\mathbf{A}\mathbf{x} = \mathbf{b}$  where  $\mathbf{x} = \mathbf{A}^{-1}\mathbf{b}$ .

If  $\mathbf{A}^{-1} = \mathbf{A}^T$  matrix  $\mathbf{A}$  is called **orthogonal**.

The inversion procedure requires appropriate **numerical procedures** (for instance, the **Cholesky** method).

- Eigenvalues  $\lambda_i$  of a symmetric matrix of  $\mathbf{A}$  ( $n \times n$ ):

$$(\mathbf{A} - \lambda_i \mathbf{I})\Phi_i = \mathbf{0} \quad \text{where} \quad \det|\mathbf{A} - \lambda_i \mathbf{I}| = 0$$

$\Phi_i$  represent the eigenvector related to eigenvalue  $\lambda_i$ . There are  $n$  such eigenvalues  $\lambda_i$  to each of which corresponds an eigenvector  $\Phi_i$ . Such vectors can be shown to be orthonormal ( $\Phi_i^T \Phi_j = \delta_{ij}$ , where  $\delta_{ij} = 1$  if  $i = j$ , 0 if  $i \neq j$ ). The physical meaning is to find a vector  $\mathbf{A}\Phi$  parallel to the vector  $\Phi$ .

## In Structural Mechanics...

... matrices are used to describe the state of strain and stress; the eigenvalues to find the principal stresses and deformations

# VECTORS

---



Co-funded by the  
Erasmus+ Programme  
of the European Union



Environmental Risk Assessment and Mitigation on Cultural  
Heritage Assets in Central Asia

A vector is a segment with an orientation, i.e., a segment with an arrow in one of its ends, described through:

- **modulus**: the length of the vector (representing, in a determined scale, the quantity)
- **bearing**: identified bundle of lines parallel to the one onto which the vector lies
- **direction**: identified by the arrow

A **unit vector** is a vector with modulus equal to 1.

### Vectors are used to represent...

... positions of points, forces, velocity and the displacements in a three-dimensional space

Three mutually orthogonal unit vectors (for example,  $\mathbf{i}$ ,  $\mathbf{j}$  and  $\mathbf{k}$ ), applied in point O, i.e., the origin of the 3D space, represent a **base**.



Any generic vector  $\mathbf{u}$  can be expressed as  $\mathbf{u} = u_x\mathbf{i} + u_y\mathbf{j} + u_z\mathbf{k}$ , where  $u_x$ ,  $u_y$ ,  $u_z$  are the **components** of the vector.

### A vector applied in O, with the tip of the arrow in P...

... can have different mathematical representations:

$$\overrightarrow{OP} = (P - O) = \vec{u} = \{u\} = \underline{u} = \mathbf{u} = \{u_x, u_y, u_z\} = \begin{Bmatrix} u_x \\ u_y \\ u_z \end{Bmatrix}$$

# VECTORS: A MODERN WAY TO USE THEM?



- Sum/difference  $\mathbf{c} = \mathbf{a} \pm \mathbf{b}$ .

$$\mathbf{c} = (a_x \pm b_x)\mathbf{i} + (a_y \pm b_y)\mathbf{j} + (a_z \pm b_z)\mathbf{k}$$

The sizes of  $\mathbf{a}$  and  $\mathbf{b}$  must be identical.

The sum can be done **geometrically** (parallelogram law).

- Length (or modulus) of  $\mathbf{u}$ .


$$u = \|\mathbf{u}\| = \sqrt{\sum_i u_i^2} = \sqrt{u_x^2 + u_y^2 + u_z^2}$$

- Dot product (symbol “.”).

Links two vectors, for example  $\mathbf{F}$  and  $\mathbf{s}$ , to a scalar quantity  $a$ :

$$a = \mathbf{F} \cdot \mathbf{s} = \|\mathbf{F}\| \|\mathbf{s}\| \cos \vartheta = F S \cos \vartheta$$

where  $F = \|\mathbf{F}\|$  represents the modulus of  $\mathbf{F}$ ,  $s = \|\mathbf{s}\|$  the modulus of  $\mathbf{s}$  and  $\vartheta$  the angle between  $\mathbf{F}$  and  $\mathbf{s}$ .



**Dot product is used for calculating...**

... the work done by a force




- Cross product (symbol “ $\wedge$ ”).

Links two vectors  $\mathbf{u}$ ,  $\mathbf{v}$  to a third vector  $\mathbf{w} = \mathbf{u} \wedge \mathbf{v}$ , **orthogonal** to  $\mathbf{u}$  and  $\mathbf{v}$  (following right-hand side convention rule), of modulus:

$$||\mathbf{w}|| = ||\mathbf{u} \wedge \mathbf{v}|| = ||\mathbf{u}|| ||\mathbf{v}|| \sin \vartheta = v u \sin \vartheta = v b$$

The angle between  $\mathbf{u}$  and  $\mathbf{v}$  is  $\sin \vartheta = \frac{||\mathbf{w}||}{||\mathbf{u}|| ||\mathbf{v}||}$



**Notice that...**

...  $\mathbf{u} \wedge \mathbf{v} \neq \mathbf{v} \wedge \mathbf{u}$ ; it is  $\mathbf{u} \wedge \mathbf{v} = -\mathbf{v} \wedge \mathbf{u}$

## Cross product is used for calculating...

... the **moment** of a force with respect to pole O ( $\mathbf{r}$  links O to P), which modulus is :

$$||\mathbf{M}|| = M = ||\mathbf{r} \wedge \mathbf{F}|| = ||\mathbf{r}|| ||\mathbf{F}|| \sin \vartheta = r F \sin \vartheta = F b$$

where  $b$  is the **lever arm**, i.e., the distance **orthogonal** to  $\mathbf{F}$  with respect to the pole O

The cross product can also be written as:

$$\mathbf{w} = \mathbf{u} \wedge \mathbf{v} = \det \begin{bmatrix} \mathbf{i} & \mathbf{j} & \mathbf{k} \\ u_x & u_y & u_z \\ v_x & v_y & v_z \end{bmatrix}$$

i.e.,

$$\mathbf{w} = \mathbf{u} \wedge \mathbf{v} = \mathbf{i}(u_y v_z - u_z v_y) - \mathbf{j}(u_x v_z - u_z v_x) + \mathbf{k}(u_x v_y - u_y v_x)$$

Find the moment of  $\mathbf{F} = \{2, 3, 0\}$ , applied in  $P(3,2,0)$ , with respect to the origin (i.e.,  $\mathbf{r} = \{3, 2, 0\}$ ).

**Solution.**

$$\mathbf{M} = \mathbf{r} \wedge \mathbf{F} = \det \begin{bmatrix} \mathbf{i} & \mathbf{j} & \mathbf{k} \\ 3 & 2 & 0 \\ 2 & 3 & 0 \end{bmatrix}$$

so that

$$\mathbf{M} = \mathbf{i}(2 \times 0 - 0 \times 3) - \mathbf{j}(3 \times 0 - 0 \times 2) + \mathbf{k}(3 \times 3 - 2 \times 2) = 5\mathbf{k}$$


It means that the moment of  $\mathbf{F}$  is a vector directed to  $z$  axis of modulus equal to 5.

The angle between  $\mathbf{r}$  and  $\mathbf{F}$  is:

$$\sin \vartheta = \frac{||\mathbf{M}||}{||\mathbf{r}|| ||\mathbf{F}||} = \frac{5}{\sqrt{13} \times \sqrt{13}} = \frac{5}{13} \quad \text{i.e., } \vartheta \approx 22.6^\circ$$

The arm of  $\mathbf{F}$  with respect to the origin of axes is:

$$b = \sqrt{13} \sin 22.6^\circ = 1.39$$




# ROTATION OF THE REFERENCE SYSTEM

A rotation of the reference system turns the components  $\{u, v\}$  of a vector denoted as  $\mathbf{r}$  in the reference system  $(x, y)$  into  $\{u^*, v^*\}$ , i.e., the components of the **same vector** in the rotated reference system  $(x^*, y^*)$  (denoted as  $\mathbf{r}^*$ ):

$$\mathbf{r}^* = \begin{bmatrix} u^* \\ v^* \end{bmatrix} = \begin{bmatrix} \cos \theta & \sin \theta \\ -\sin \theta & \cos \theta \end{bmatrix} \begin{bmatrix} u \\ v \end{bmatrix}$$

that is  $\mathbf{r}^* = \mathbf{N}\mathbf{r}$ , where  $\mathbf{N}$  is an **orthogonal** matrix ( $\mathbf{N}^T = \mathbf{N}^{-1}$ ) that does not change the length of the vector:

$$\|\mathbf{r}^*\| = \sqrt{(u^*)^2 + (v^*)^2} = \|\mathbf{r}\| = \sqrt{u^2 + v^2}$$



## EXAMPLE: ROTATION OF THE REFERENCE SYSTEM

Find the components of vector  $\mathbf{a} = \{3, -1\}$  in a new frame rotated of  $\frac{\pi}{6}$  counterclockwise.

**Solution.** Matrix  $\mathbf{N}$  is given by:

$$\mathbf{N} = \begin{bmatrix} \cos \frac{\pi}{6} & \sin \frac{\pi}{6} \\ -\sin \frac{\pi}{6} & \cos \frac{\pi}{6} \end{bmatrix} = \begin{bmatrix} \frac{\sqrt{3}}{2} & \frac{1}{2} \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} \end{bmatrix}$$

so that:

$$\mathbf{a}^* = \mathbf{N}\mathbf{a} = \begin{bmatrix} \frac{\sqrt{3}}{2} & \frac{1}{2} \\ -\frac{1}{2} & \frac{\sqrt{3}}{2} \end{bmatrix} \begin{bmatrix} 3 \\ -1 \end{bmatrix} = \begin{bmatrix} \frac{3\sqrt{3}-1}{2} \\ -\frac{3+\sqrt{3}}{2} \end{bmatrix} \approx \begin{bmatrix} +2.1 \\ -2.4 \end{bmatrix}$$

# DIFFERENTIAL EQUATIONS

---



Co-funded by the  
Erasmus+ Programme  
of the European Union



Environmental Risk Assessment and Mitigation on Cultural  
Heritage Assets in Central Asia



A **differential equation** is a mathematical equation that relates some function with its derivatives.

As example, the **vertical motion of an object falling** (uniform gravitational field without air resistance) is examined:

$$a(t) = \frac{dv(t)}{dt} = +g$$

$$dv(t) = +g dt$$

$$\int dv(t) = \int g dt + C_1 = g \int dt + C_1$$

$$v(t) = g t + C_1$$



It is also:

$$\begin{aligned}
 v(t) &= \frac{dy(t)}{dt} = g t + C_1 \\
 dy(t) &= (g t + C_1) dt \\
 \int dy(t) &= \int (g t + C_1) dt + C_2 \\
 y(t) &= \frac{1}{2} g t^2 + C_1 t + C_2
 \end{aligned}$$

where  $g$  is the acceleration due to **gravity** ( $9.81 \text{ m/s}^2$  near the surface of the earth).

The boundary conditions are  $v(0) = 0$  and  $y(0) = 0$  so that  $C_1 = C_2 = 0$ . Hence:

$$v(t) = g t$$

$$y(t) = \frac{1}{2} g t^2$$

The velocity of an object after a fall from a height  $h$  is:

$$v(h) = \sqrt{2gh}$$

while the time  $t_h$  to travel the distance  $h$ :

$$t_h = \sqrt{\frac{2h}{g}}$$

